User Manual Weighing Indicator BTW



Table of Contents

Instructions for Use	2
Preparing to Use the Scale	2
Chapter 1 Introduction	4
1-1 Features 1-2 Specifications 1-3 Display	4 4
1-4 Keypad Functions Description 1-5 Power Supply 1-6 Error Massage	5
Chapter 2 Operating Introduction	6
2-1 Keypad Operating 2-2 Self Test Mode 2-3 General Function Operating 2-3-1 Simple Counting Function	7 8
2-3-2 Check Weighing Function	10 11
2-4-1 General Setting	13 13
2-4-3 External Weight Calibration2-4-4 Transmission Setting	
Appendix 1 7-Segment Display Characters	17
Appendix 2 Installation	18

Thank for your purchasing of our Weighing Scale. To guide you to use our product correctly, please read this User Manual carefully to extend the life of machine and to avoid error.

Instructions for Use

- 1. Please keep scale in a cool and dry place. Do not store under high temperatures.
- 2. Please keep the scale clean and free from insect infestation.
- 3. Avoid impacting with other items or overloaded with excessively heavy weights. (The load must not exceed the maximum capacity of the scale).
- 4. If the scale is not going to be used for some time, please clean it and store it in a plastic bag in dry condition. A desiccant sachet may be included to prevent moisture from building up.
- 5. Please operate or charge the scale in an open area. Do not squeeze the power cord to avoid wire on fire.
- 6. Any suggestion is warmly welcome.

Preparing to Use the Scale

- Locate the scale on a firm level surface free from vibrations for accurate weight readings.
 Adjust the four leveling feet to centre the leveling bubble on the scale.
- 2. Avoid hot sunshine directly on the scale or near the exhaust port of ventilating system.
- 3. Please use a separate power source plug, to avoid the disturbance of other electric appliance.
- 4. There should be no weight on the scale when power is turned on.
- 5. Commodity should be placed at the centre of platter when being weighed, and its size should not exceed the dimension of the platter.
- 6. We suggest to warm the scale for 15 ~ 20 minutes before using.
- 7. Please note that when symbol shows up on the display, which means the indicator needs to be charged. The indicator could only operate for another 6~8 hours. Then "- '__ " will show on the display and the indicator must be fully charged before operating again.
- 8. Introduction of Storage Battery


Due to the storage battery adopt the advanced free-maintaining technique, customers need not to replenish electrolyte.


The scale should be recharged every 3 months to prevent failure of the internal rechargeable battery.

- 1. The battery should be charged for 8~10 hours.
- 2. The temperature of battery should below 45°C.

Maintaining

- 1. Please do not discharge with over-current when using the battery. Please charge the battery after discharging current.
- 2. Please take down the battery when the scale is not used for a long time or break the connection of cathode.
- 3. Do not short the battery terminals to check whether there is current. Please check whether the connection point is firm to guarantee good connection.
- 4. The battery should be replaced by specialized person. No reverse-battery or the product will be damaged.
 - a) Anode of battery should be connected with Anode of product battery (usually red cable)
 - b) Cathode of battery should be connected with Cathode of product battery (usually brown cable or black cable)





Safety warnings

- 1. The electrolyte of battery is caustic which causes metal, cotton, etc to corrode.
- 2. The hydrogen will be resolved when using or charging the battery and it will cause explosion when approaches fire.









No burning

Caution Corrosion Warning explosion

Children faraway

Chapter 1 Introduction

1-1 Features

- The interface is simple and easy to operate
- Up to 1/15,000 display resolution
- High Speed 24bits AD
- AC / DC switching function (Built-in rechargeable battery)
- Low power indication
- LCD display (Weight-6 digits); Full range tare; Auto zero tracking
- Simple counting; Gross/Net indication; Hold function
- Check mode Lo / Hi / OK with 3 selectable beeping sounds
- Lo / Hi / OK indication shows on LED lights
- Selectable unit: Kilogram (kg) and pound (lb)
- Easily viewing single weight / total weight within 1 button press


Option:

- RS232: Bi-direction transmission, easy data reading or printing
- Sleeve connecting stand

1-2 Specifications

- Display LCD 6 digits, Height 25mm, LED Backlight
- Indicator Dimensions: 235 x 163 x 133 mm (W x H x D)

1-3 Display



Icon Introduction

→o← : "Zero" indication

When the weight is negative, this icon appears.

Net: Put container on the platter, after stable and press tare key and the "Net" appears.

: "Low battery power" indication

kg: "kg" unit

f: "Taiwan Tael" unitPcs: Counting mode%: Percent indication

HI: The weight is higher than setting value, "HI "LED on

OK: When the weight is between HI limit values and LO limits value, "OK "LED on

LO: The weight is lower than setting value, "LO "LED on

▼ 1 : "STABLE" indication

▼ 2 . "GROSS" indication. When the object is in net mode and press F key, this icon

· appears

▼ 3 : "M+" indication ▼ 4 : "PT" indication

▼ **5** : Range 2 ▼ **6** : Range 1

• 7 : When this LED is on, the indicator is charging.

1-4 Keypad Functions Description

key	Function	Hold the key for 1 sec.	Hold the key for 3 sec.
→0 ←	Zero key	Check Voltage	
↔ ĵ>	Tare/Pre-tare key	Backlight setting Zero display setting Local G value setting	
UNIT	Unit key		Enter password to enter external weight calibration
F	Function key		
<u>©</u>	Print / transmit key	RS-232 transmission setting	

1-5 Power Supply

Power Selection

6V 4Ah / 4V 4Ah rechargeable battery

110V/230V AC Adaptor

Power Consumption

White backlight: about DC 37.7 mA

Green backlight: about DC 12.95mA for 4V models; about DC 14.67mA for 6V models

LED charging icon

When "- - - shown on the display, the indicator must be charged. When the charging icon becomes red, it means the indicator is charging; when the charging icon becomes green, it means the indicator is fully charged.

The indicator needs to be charged for about 8~9 hours when "- '___ -" shown on the display.

1-6 Error Massage

 $\Xi \Box \Rightarrow$ The EEPROM is not working correctly.

(The EEPROM is not set yet, or the circuit on PCB is broken.)

 $\Xi \quad \Rightarrow$ Zero is higher than the zero range when switching the indicator on.

 $\Xi \Rightarrow$ Zero is lower than the zero range when switching the indicator on.

 $\Xi \dashv \Rightarrow A/D$ value is unstable

 \Rightarrow ADIC value is over the maximum range. (2097151 ~ -2097152)

 $\neg \neg \vdash \Rightarrow$ The weight of the object is under -1/6 maximum capacity.

Chapter 2 Operating Introduction 2-1 Keypad Operating

transparent transparent to the scale and the maximum capacity. Tare Function Place the container onto the scale, until the weight value is stable, press key for zero return and the NET indication is shown on the display. Place the object into the container and the display shows the net weight value of the object. Remove both object and container, and negative value of the container will show on the display. Press display. Press display gain to clear "tare value". The scale returns to zero and NET indication goes off. Tare can be continuously done until tare value=maximum capacity. Continuous Tare ⇒ Press key for continuous weight increase/decrease on platter. If there is Tare, the pre-tare cannot be done. If there is pre-tare first, and the tare weight is more than pre-tare weight, Tare can be done. No Tare can be done under gross weight display mode. Pre-Tare Function When there is nothing on the platter, press key and use keypad to input pre-tare weight When the cursor flashes on the last digit of display, press key again to complete. Method of clearing Pre-tare value: the same as the method of clearing tare value. Pre-tare mode, keypad function as followed: Description with the cursor flashes on the last digit of display, press weight display to complete. Pre-tare mode, keypad function as followed: Description weighing mode, use this key to shift among simple counting function, check weighing function, accumulation function and hold function. In tare mode, use this key to shift between the "Net value" and the "Gross value". Shift between Net value and Gross value In the Tare mode, the "Net" icon shows up. Press key, the screen displays the "gross weight" and when the "GROSS" icon value with the "Net" icon shows up, the "GROSS" icon value weight" and when the "Net" icon shows up, the "GROSS" icon value weight" and when the "Net"	: Zero key
t can be tare except when the weight is negative and the maximum capacity. Tare Function Place the container onto the scale, until the weight value is stable, press key for zero return and the NET indication is shown on the display. Place the object into the container and the display shows the net weight value of the object. Remove both object and container, and negative value of the container will show on the display. Press was again to clear "tare value". The scale returns to zero and NET indication goes off. Tare can be continuously done until tare value=maximum capacity Continuous Tare ⇒ Press key for continuous weight increase/decrease on platter. If there is Tare, the pre-tare cannot be done. If there is pre-tare first, and the tare weight is more than pre-tare weight. Tare can be done. No Tare can be done under gross weight display mode. Pre-Tare Function When there is nothing on the platter, press key and use keypad to input pre-tare weight When the cursor flashes on the last digit of display, press key again to complete. Method of clearing Pre-tare value: the same as the method of clearing tare value. Pre-tare mode, keypad function as followed: Define the vertical pre-tare value is a move cursor leftward Pre-tare mode, use this key to shift among simple counting function, check weighing function, accumulation function and hold function. In tare mode, use this key to shift between the "Net value" and the "Gross value". Shift between Net value and Gross value In the Tare mode, the "Net" icon shows up. Press key, the screen displays the "gross weight" and when the "GROSS" icon vertical shows up, "Net" icon shows up, the "GROSS" icon vertical solution and when the "net weight" and when the "Net" icon shows up, the "GROSS" icon vertical shows up, "Net" icon shows up, the "GROSS" icon vertical shows up the "GROSS" icon vertical shows up, the "GROSS" ico	If the weighing value is within the range of zero balance, it can be re-zeroed and tare cancelled.
Tare Function ● Place the container onto the scale, until the weight value is stable, press key for zero return and the NET indication is shown on the display. ● Place the object into the container and the display shows the net weight value of the object. ● Remove both object and container, and negative value of the container will show on the display. Press way again to clear "tare value". The scale returns to zero and NET indication goes off. ■ Tare can be continuously done until tare value=maximum capacity © Continuous Tare ⇒ Press way key for continuous weight increase/decrease on platter. ■ If there is Tare, the pre-tare cannot be done. If there is pre-tare first, and the tare weight is more than pre-tare weight, Tare can be done. ■ No Tare can be done under gross weight display mode. Pre-Tare Function When there is nothing on the platter, press way key and use keypad to input pre-tare weight when the cursor flashes on the last digit of display, press way key again to complete. Method of clearing Pre-tare value: the same as the method of clearing tare value. Pre-tare mode, keypad function as followed: ■ upward key	•
 Place the container onto the scale, until the weight value is stable, press	It can be tare except when the weight is negative and the maximum capacity.
Pre-Tare Function When there is nothing on the platter, press key and use keypad to input pre-tare weight When the cursor flashes on the last digit of display, press key again to complete. Method of clearing Pre-tare value: the same as the method of clearing tare value. Pre-tare mode, keypad function as followed: →0 → upward key	 Place the container onto the scale, until the weight value is stable, press key for zero return and the NET indication is shown on the display. Place the object into the container and the display shows the net weight value of the object. Remove both object and container, and negative value of the container will show on the display. Press again to clear "tare value". The scale returns to zero and NET indication goes off. Tare can be continuously done until tare value=maximum capacity Continuous Tare ⇒ Press key for continuous weight increase/decrease on platter. If there is Tare, the pre-tare cannot be done. If there is pre-tare first, and the tare weight
When there is nothing on the platter, press when the cursor flashes on the last digit of display, press when the cursor flashes on the last digit of display, press when the cursor flashes on the last digit of display, press when the cursor flashes on the last digit of display, press when the cursor flashes on the last digit of display, press when there is nothing on the platter, press when the cursor flashes on the last digit of display, press when the cursor flashes on the last digit of display, press when the cursor flashes on the last digit of display, press when the cursor flashes on the last digit of display, press when the cursor flashes on the last digit of display, press when the cursor flashes on the method of clearing tare value. when the cursor flashes on the method of clearing tare value. when the cursor flashes on the method of clearing tare value. when the cursor flashes on the method of clearing tare value. when the cursor flashes on the method of clearing tare value. when the cursor flashes on the method of clearing tare value. when the cursor flashes on the method of clearing tare value. when the cursor flashes on the method of clearing tare value. when the cursor flashes on the method of clearing tare value. when the cursor flashes on the method of clearing tare value. when the cursor flashes on the method of clearing tare value. when the cursor flashes on the method of clearing tare value. when the cursor flashes on the method of clearing tare value. when the cursor flashes on the method of clearing tare value. when the cursor flashes on the method of clearing tare value. when the cursor flashes of clearing tare value. when the cursor flashes on the method of clearing tare value. when the cursor flashes on the method of clearing tare value. when the cursor flashes on the method of clearing tare value. when the cursor flashes on the method of clearing tare value. when the cursor flashes on the meth	No Tare can be done under gross weight display mode.
 F : Function key In weighing mode, use this key to shift among simple counting function, check weighing function, accumulation function and hold function. In tare mode, use this key to shift between the "Net value" and the "Gross value". Shift between Net value and Gross value In the Tare mode, the "Net" icon shows up. Press F key, the screen displays the "gross weight" and when the "GROSS" icon ▼ shows up, "Net" icon goes off. Press F key again the screen displays the "net weight" and when the "Net" icon shows up, the "GROSS" icon ▼ goes off. 	When there is nothing on the platter, press key and use keypad to input pre-tare weight When the cursor flashes on the last digit of display, press key again to complete. Method of clearing Pre-tare value: the same as the method of clearing tare value. Pre-tare mode, keypad function as followed:
 Function key In weighing mode, use this key to shift among simple counting function, check weighing function, accumulation function and hold function. In tare mode, use this key to shift between the "Net value" and the "Gross value". Shift between Net value and Gross value In the Tare mode, the "Net" icon shows up. Press F key, the screen displays the "gross weight " and when the "GROSS" icon ▼ shows up, "Net" icon goes off. Press F key again the screen displays the "net weight" and when the "Net" icon shows up, the "GROSS" icon ▼ goes off. 	UNIT ⇒ downward key → move cursor rightward
In the Tare mode, the "Net" icon shows up. Press F key, the screen displays the "gross weight " and when the "GROSS" icon ▼ shows up , "Net" icon goes off. Press F key again the screen displays the "net weight" and when the "Net" icon shows up , the "GROSS" icon ▼ goes off .	 Function key In weighing mode, use this key to shift among simple counting function, check weighing function, accumulation function and hold function.
In the Tare mode, the "Net" icon shows up. Press F key, the screen displays the "gross weight" and when the "GROSS" icon ▼ shows up, "Net" icon goes off. Press F key again the screen displays the "net weight" and when the "Net" icon shows up, the "GROSS" icon ▼ goes off.	Shift between Net value and Gross value
except the F key, have no response.	In the Tare mode, the "Net" icon shows up. Press F key, the screen displays the "gross weight" and when the "GROSS" icon ▼ shows up , "Net" icon goes off. Press F key again the screen displays the "net weight" and when the "Net" icon shows up , the "GROSS" icon ▼ goes off . When the screen displays the "gross weight" (the "GROSS" icon ▼ shows up), keys

UNIT : Unit key

Use | UNIT | key to select a unit as the display indicated.

The selected unit will be memorized when you turn the indicator off. And the memorized unit will appear after you turn on the indicator next time.

○ : Print key


In accumulation mode, if the parameter set as $\neg \neg \Box \Box$ or $\neg \neg \Box \Box$ transmission, it transmits the format of simple mode or complete mode.

This key is the combination key. while total counts is shown and weight returns to net zero, press (a) key to clear data and RS-232 transmits the MC printing format.

- If there is new weight added on platter, a new data will be added to accumulation data. If this weight is not taken off, nothing can be added to accumulation data. Display will show the total counts for one second, then show net weight for one second, then the display returns to the current weight.
- © key again to clear accumulation data.
- Weight must return to net zero if to perform clear function

2-2 Self Test Mode


Press key and not release. Then power on the indicator, Wait till display shows to enter "Self-Test Mode"



☐ ☐ ☐ INTERNAL VALUE MODE (must hook up full-bridge Load Cell to test)
⊕ Press to enter, and the display shows internal value □ Press → to enter, and the display shows internal value □ Press → to enter, and the display shows internal value □ Press → to enter, and the display shows internal value □ Press → to enter, and the display shows internal value □ Press → to enter, and the display shows internal value □ Press → to enter, and the display shows internal value □ Press → to enter, and the display shows internal value □ Press → to enter, and the display shows internal value □ Press → to enter, and the display shows internal value □ Press → to enter, and the display shows internal value □ Press → to enter, and the display shows internal value □ Press → to enter, and the display shows internal value □ Press → to enter → to
$\ @$ Please check the internal value is within normal range $\ (\ 0\sim400000\ no\ load\)\ \circ$
③ Check whether the backlight is on
④ Press →0← key to back to the last screen, the display shows ☐ ' 日己딘
□ 근 남 등님 KEYPAD TEST MODE
① Press ∰ to enter, display shows 坮 ℇ닠 З І
② Keypad's internal code: ₩ key = 01 \ UNIT key = 31 \
③ Press →0← key to back to the last screen, the display shows ☐ 글 ㅂ ㅌ ㅂ
☐ ∃ ☐ E FIRMWARE VERSION DISPLAY MODE
⊕ Press to enter, display shows the firmware version □□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□
② Press ∰ key again, the display shows maintenance number ☐ ☐ ☐ for 2 seconds
③ Press →0← key to back to the last screen, display shows ☐ ☐ ☐ ☐ ☐ ☐
□□ E □ E BACK TO THE LAST SCREEN
Press ₩ key to exit self-test mode, the scale will re-power on automatically

2-3 General Function Operating

Power on the indicator and enter into the setting that you set before or weighing mode. Then press [F] to shift functions




2-3-1 Simple Counting Function

1. In weighing mode, press key to enter into simple counting function.

2. Press key to select sample quantity (10, 20, 50, 100, 200) LCD shows as right picture:

Press *0* key

3. Select sample quantity and then place samples on the platter. After stable, press (a) key and display shows -----. After stable, the scale enters into counting mode and the display shows sample.



4. Press F key to enter into next function.


2-3-2 Check Weighing Function

1. In weighing mode, press F key twice to enter into check weighing function. 2. Press will key to enter into beeper setting. LCD shows as right picture: 3. Press key to select beep sound. Press UNIT kev i-, Beeper setting between Low limit & High limit.), the beeper beeps. Press [↔] kev □ □ ⇒When the weight is under **占** 근 or equal to Low limit & over or equal to High limit, the Press ₩ key beeper beeps. 노글 Press ₩ kev 4. Press will key to enter into Hi limit value setting 5. key⇒move cursor to right ł ⊱, (When the cursor arrive to the last Digit, it returns to the first digit.) Press UNIT key →0← key⇒increase/decrease number | | LIVIT | | Kev⇒confirm and enter into Lo Hi limit value setting limit value setting 6. In Lo limit value setting Press UNIT kev **UNIT** key⇒confirm and return to 0 :000 Beeper setting Lo limit value setting Press UNIT key to confirm and return to Beeper setting H 7. In beeper setting, press key to enter into check weighing function. When Press e key the weight is more than 10d, check weigh-Check weighing ing function activates. function 8. Press F key to exit the setting and Shift "Hi,OK,LO " LED light enter into next function. Put weight (>10d) according Hi-Lo limit value Repeat above steps to set this function again. **∤**setting Units can not be shift in check weighing function. Please enter into weighing mode OK

to shift units

2-3-3 Accumulation Function


1. In weighing mode, press key three times to enter into accumulation function. LCD shows as following picture:




- ☐ ☐ ☐ ☐ ☐ I ⇒ Manual accumulation: After the weight is stable, press weight is stable, press and "M+" icon shows up. It does the second accumulation, after the weight returns to zero.
- ☐ ☐ ☐ ⇒Automatic accumulation: After the weight is stable, it accumulates automatically, and "M+" icon ▼ shows up. It does the second accumulation, after the weight returns to zero.
- The Minimum weight of accumulation: > 10d

If the weight is unstable while accumulating, display shows □□급급□□.

2. Press LINIT key to see accumulation counts and accumulation weight.







- 3. Press key to exit the setting and enter into next function.
- Repeat above steps to set this function again.

mode

2-4 Further Function Operating



- Local G value conditions: The new Local G values must be within ±10% of the Local G value set in the factory.
- following If the external weight calibration has been used, the Local G value is disable.
- To enable it, please switch the jumper SWA1 to ADJ position first. Then do Weight Calibration Setting [] [(See 3-2-1).




mode after 3 second

02023032/02023042 13 ZSME3000000319

2-4-3 External Weight Calibration

In weighing mode and the weight returns to zero, Press UNIT key for 3 second to enter into password display. Press will returns to weighing mode.





Weight calibration conditions:

The calibration weight value placed on the platter must be over 100e, and the standard deviation of the weight must be within ±10%.

2-4-4 Transmission Setting

1. In weighing mode, press key for 1 second to enter into transmission setting.





RS-232 Output Format

The output format of call land call 2

_ THE OUI	Juli	OIIII	at Oi	. ,	• •	. 0	ii iu		-											
GROSS	ഗ	Т	,	G	S	,	+	1	2	3	4	5	6	7	SP	SP	0	Z		
Net	ഗ	Т	,	Z	Т	,	+		2	3		4	5	6	t			g		
Plus OL	0	Ш	,	G	S	,	+	SP	CR	LF										
Minus OL	0	Ш	,	G	S	,	ı	SP												
Unstable	כ	S	,	G	S	,	+	1	2	3	4		5	6	SP	SP	-	Ь		

it transmit above format. It transmits next data format only when take off the weight on the platter and put it on again.

<u>-58</u> 3	⇒Press⊚ key to	transmit (simple mod	de): use in accumulation mode.				
Steps:	1. Press F key and select ∃ □ □ I. Press key to enter into weighing mode.						
	2. Select \Box	∃ and necessary ba	aud rate.				
	3. Put the objects	on the platter. After the	he weight stable, press key to				
	accumulate the following exam	e data and print out the	e order and the net value of the data a	S			
	· —	step to accumulate ar	•				
	•	•	as following example and clear the dat	a.			
	S/N 	WT 					
	0001	2.500	☜ Press 🧕 key				
	0002	2.500	Press of key □ Press of key				
	0003	2.500	Press				
	0003	7.500	Press key twice to print TOT	ΆL			
-5 8 4	⇒Press⊚ key to	transmit (complete m	node): use in accumulation mode.				
Steps:	1. Press F key		Press key to enter into weighing				
	mode.						
		'-' and necessary ba					
	_		he weight stable, press loley to e data as following example.				
	TICKET NO.		s data as following example.				
		00kg					
		00kg					
	NT 2.50	00kg	Press key				
	<u> </u>	step to accumulate ar					
			s following example and clear the data				
	TOTAL NUM						
	OF TICKET						
	TOTAL WE	2.500kg	Press	AL			
		· ·					
-07 D	mode.		same as rā P 3) in accumulation				
Steps:	mode.		'. Press key to enter into weighing				
	2. Select	⊆ and necessary ba	aud rate.				
	-	ne data and print out th	he weight stable, it automatically he order and the net value of the data	as			
	•	step to record and pri	nt continuously.				
			as following example and clear the data	a.			
	•						

Appendix 1 7-Segment Display Characters

Number	Display	Letter	Display	Letter	Display
0	8	А	8	N	
1	8	В	Œ	0	Œ
2	00	С	Ш	Р	
3	8	D	8	Q	
4	<u> </u>	E	8	R	
5	8	F		S	ūĐ
6	8	G	8	Т	Œ
7		Н		U	
8	8	I		V	
9	8	J	80	W	00
		К	111	Х	
		L		Y	8
		М	8	Z	8

Appendix 2 Installation

 Please connect the Load Cell and Indicator as following 5PIN Connector

PIN 1 E+

PIN 2 E-

PIN 3 S+

PIN 4 S-

PIN 5 GND




2. Connecting way of a 9 pin RS-232 connector as following.

PIN 2: Data inputting (TXD), position 2 in following picture

PIN 3: Data outputting (TXD), position 3 in following picture

PIN 5: Internal grounded (GND), position 5 in following picture



Relay Output

1. Principle of operation

Use check weighing function to set the ranges of High, OK, LOW. If the weight is between the ranges of LOW, the data will output in LOW port; If the weight is between the ranges of OK, the data will output in OK port; If the weight is between the ranges of High, the data will output in High port;

Please refer to check weighing function to set the ranges of High, OK, LOW.

2. Connecting ways and function

Terminal Block	Connector's PIN	Function
A1	PIN 1	High Output
B1	PIN 2	OK Output
C1	PIN 3	Low Output
COM	PIN 4	COMMON