



D20


Digital Electronic Weighing Indicator

Technical Manual

Version: June, 2012

- Please read this manual carefully before using
- Please keep this manual properly for reference

KELI SENSING TECHNOLOGY (NINGBO) CO., LTD



- ▲ **Indicator ground wire must be complying with electrical safety regulations, junction box; load cell must be well grounded.**
- ▲ Connection between digital load cell and indicator must be reliable, load cell shield wire must be grounded.
- ▲ all cable does not allow plug / unplug when indicator is connecting to power supply, to protect indicator or load cell from electrostatic.
- ▲ Thunderstorm season, system must have reliable lightning protection measures, to protect load cell and indicator.
Make sure operators' safety and weighing equipments running safely.
- ▲ limited using for flammable gas, or flammable vapor areas, or tank system with pressure.
- ▲ keep indicator and load cell away from strong electric magnetic field, corrosive substances and explosive materials.
- ▲ do not sue strong solvents(such as: benzene, nitro-class oil) to clean the cover.
- ▲ do not inject liquid or other conductive particles into indicator.
- ▲ **without technical supervision department's promise, no one can open the seals, or calibrate..**
- ◆ **to ensure indicator display clearly, and work longer, do not use it under direct sunlight, and put it stable.**
- ◆ indicator should be away from dust, vibration, wet environment.
- ◆ before plugging/unplugging, pls cut off indicator or other equipments' power.
- ◆ connecting each connector as the manual book.
- ◆ That indicator is precision measuring instrument, to ensure accuracy, do not open it without authorization.
- ◆ exceeding maintenance time, factory should charge for repairing.

Catalogue

one : Technical parameter	5
Three : Installation and connection.....	7
Indicator and digital load cell connection	7
Indicator and scoreboard connection	7
Indicator and computer connection.....	8
Indicator and battery connection	8
Four : Digital load cell debuggin.....	8
Modifying load cell communication address, and scale digital load cell.....	8
Section Two Pressing corner to identify the digital load cell address.....	10
Section Three ISN code for each corner.....	10
Section IV Corner-difference correction	11
One, Automatical corner difference correction.....	11
Two, Axle corner difference correction function.....	12
Three, Enter weight for corner difference correction.....	13
Four, Enter corner coefficient for corner difference correction.....	14
Chapter V. Calibration	14
1. Calibration.....	14
2. Division auto switch and calibrate linearity.....	16
Chapter IV. Other Operation.....	17
1. Date and time setting.....	17
2. Calibration password management	17
6.3 Timing Off.....	18
①、The way to set the expire date of probation.....	18
②、Remove and modify the timing off:.....	18
6.4 Cancel password of calibration temporarily.....	18
6.5 The way to set the expire date of probation.....	18
①、setting the expire date of probation.....	18
②、Remove and modify expire date of probation.....	19
③、Setting password of expire date.....	19
④、Randomly cancel date of probation.....	19
6.6 System testing.....	20
①、checking ISN of each corner.....	20
②、Check overloading record.....	20
④、Check check program configuration and version number.....	21
⑤、Check the last calibration zero for each sensor internal code value.....	21
⑥、Check the battery voltage.....	22
⑦、Check the key function and instrument PC interface RS232 communication	22
function.....	22
⑧、Calibrate RS232/4-20mAOutput converter function interface.....	22
Adapter 7 PC Communication parameter Settings.....	23
Adapter eight save printing parameter Settings.....	23
Section 9 Custom infill pounds single set	24
1. Set print content: each set print content, and the specific meaning of the parameters is set up as follows :	24
Section 10. The initialization function.....	28



This interface includes all parameter initialization , Now an initialization angle difference coefficient operation shows as below , The rest of the operation is the same as this one.....	28
Section 12. Set print company name.....	28
Chapter 7 Hardware introduction.....	30
7.1 Whole Structure for indicator.....	30
7.2 Mainboard introduction.....	32
7.3 Introduction for Site Electric	33
Chapter 8 In formation tips.....	34
Appendix A: communication protocol.....	35
AppendixB : Example weighing record sheet format :	40

one : Technical parameter

1 Type : D20

2 Digital load cell interfaces:

Communication mode RS485

Signal transmission distance: 30 m if connecting 12 pcs load cells, if need longer, pls contact us.

Transmission baud rate 9600、19200bps

Excitation power DC12~14.8V

Digital interface ability connect max 16 pcs digital load cells

Available communication protocol : C type、E type and K type ditial protocols.

3 Display : 7 digits of LED , 7 digits of status symbols

4、 keyboard

Number keys 0 ~ 9

Function keys 24 pcs (10 combined with number keys)

5、 clock : display year, month, date, hour, minute and second, leap year and leap month automatically.

6、 Scoreboard display interface (isolated from load cell connectors)

Transmission mode current loop and RS232

Transmission baud rate 600bps

7、 Serial communication interface (isolated from load cell connectors)

Transmission mode RS232

Baud rate: 1200/2400/4800/9600/19200 optional

8、 printing interface (isolated from load cell connectors)

With standard parallel printing interface, such as EPSON LQ-300K + II、 EPSON LQ-300K、 EPSON LQ-680K 、 EPSON LQ-730K 、 EPSON LQ-1600K (+) 、 KX-P1131、 KX-P1121、 DS-300...etc printers.

Out-connecting micro-printer : POS58 printer (thermal-printer) 、 AB_300K (needle-printer)

9、 Operating environment

Can store 1000 groups of vehicle numbers and tare weight, 1500 groups of latest weighing records, 300 groups latest unfinished weighing records, 6 groups of over load records.

10、Operating environment

Power input AC110~220V 50~60HZ

DC 12V

Operation temperature 0°C ~ 40°C


Storage temperature -25°C ~ 55°C

Relative humidity ≤85%RH

11、 sizes (mm) : 384 ×248 ×100

12、 weight (Kg) : 3.5 kg


two : scale calibration steps



Three : Installation and connection


Indicator and digital load cell connection

That indicator can connect C, E or K type digital load cells.



2. Current loop connection

Indicator and computer connection



Indicator PC connector	Computer 9 cores connector
2	2
3	3
5	5

Indicator PC connector with indicator and computer RS 232 connection

Indicator and battery connection

Indicator have auto-charging module inside, and pls use 12V/7Ah battery.

Four : Digital load cell debuggin

Modifying load cell communication address, and scale digital load cell.

Keep the address unit, and stable. Diagram 4.1.1。




Diagram 4.1.1

Solution 1、C type digital module modifying load cell communication address and setting load cell type & numbers.

C type digital module modifying load cell address, load cell must be modified one by one, other load cells should be connected from 1 to N continiously, or it can not work.

Operation :

Step	Operation	Display	Explanation
1	press 【ADD】	C-CodE	Input initial code, and not be introduced in following setps.
	press 【888888】	C- - - - -	Initial code“888888”
2	press 【input】	FunC 00	Selection function type 0 : setting address singly.
3	press 【input】	S Adr	Scan connected digital load cells. Note: if not find any load cell, indicator display Err adr .
4	press 【input】	---	scanning
5		Xd** n##	X: load cell communication protolos

	press [0] [1]	Xd** n01	1: KELI C type 2: KELI E type 3: KELI K type d** digital load cell original communication address. n## new communication address 01(range: 01~16)
6	press [input]	*****.	Displaying internal code when setting successfully. E、C can display internal code, K can not display if code is different.
7	press [input]	S Adr	Return to step 3

1、Automatic group scale after modifying address.

Operation: (calibration switch on)

Step	Operation	Display	explanation
1	press [ADD] press [1]	FunC 0 FunC 1	Selecion function type1 , scan load cell as address number, and automatically group scale.
2	press [input]	--- dno 8	scanning displaying scanned load cells' address
3	press [input]	SurE 0	Not reserve/ reserve scanned results. 0 : not reserve ; 1 : reserve
4	press [1]	SurE 1	reserve
3	press [input]	*****	Weighing interface

Method 2、 Modify the communication address for E type or K type digital load cell

There are two methods to modify digital load cells with E or K type digital module.
Method 1: Operate like C type digital load cell. Connect signal load cell to modify
address. After that run auto scale forming **[FunC 01]** . Method 2: Both digital load cell
with E and K type digital module support auto networking. Connect all of the load cells
directly. And that carry out auto networking operation. Then go ahead with the
operation steps of pressing corner to set address.

Operation method please refer to the following table: (calibration switch should be on)

Step	Operation	Display	Note
1	Press [ADD] Press [3]	FunC 00 FunC 03	Select function category number 03, E and K type digital load cell auto networking (calibration switch should be on)
2	Press [ENTER]	--- no **	Scanning Found **number digital load cells
3	Press [ENTER]	SurE 0	unsave/save scanning result 0 : unsave ; 1 : Save
4	Press [1]	SurE 1	Save scanning result and random allocation address 1~n
5	Press [ENTER]	noLoAd	Zero point confirmation, At this moment, there is no loading on scale
6	Press [ENTER] Put weight (It can also be replaced by one or several people) on the first load cell	d01 **	Set No. 1 address ** means the previous address for the current load cell If press [Enter] and display Err17 , It means repeat confirmation to this load cell address or load cell is error. Please press [Weigh] and check the each load cells stressing status according to the chapter IV, section three test 0.
7	Press [Enter] Loading on to the next load cell	d02 **	Confirm No. 2 address.
8		-----	
9	Press [Enter]	End Weighing Status	It will exit automatically after pressing the corner

Note: Step 3: It can exit to the weighing status if you press **【weigh】** at this time.

Step 6 : If press **【Enter】** and display Err17 , It means repeat confirmation to this load cell address or load cell is error. Please press **【Weigh】** and check the each load cells stressing status according to the chapter IV, section three test 0.

Section Two Pressing corner to identify the digital load cell address

When the testing person is not clear about the load cell address distribution or not sure if the load cell is pressed tight or not, the following methods can be adopt to for testing.

Operation method is as follows:

Step	Operation	Display	Note
1	Press 【TEST】	S-CodE	Enter test password
	Press 【111111】	S- - - - -	Password is fixed“111111”
	Press 【ENTER】	tESt 0	Test Main Interface
2	Press 【6】	tESt 6	Slect category number 6 and enter to identify the address by corner pressing.
3	【ENTER】 Put weight (It can also be replaced by one or several people) on a certain load cell	Adn 03	Display current load cell address Note: 03 stands for current load cell address. At this time, it will be changing according to the weight movement. Load cell communication error or press 【Weigh】 to exit to weighing interface.
4	Press 【Enter】	tESt 0	Testing Main Interface

Section Three ISN code for each corner

In order to make sure the accuracy of corner difference coefficient modification and long term stability of scale, the requirement that digital weighing system needs for foundation and mechanical installation is same as analogy scale. User shall adjust scale platform to be horizontal

Checking ISN code of each corner is helpful for adjusting scale platform. Refer to the method in Form 4-3-1

Well installed scale, the ISN code at corresponding corner should be close. As the above picture as an example: The outside circle, no.1, no.2, no.6, no.5 should be near to each other; inside circle no.3, no.4 inner code should be near and should be about double than the outside circle. The phenomena like “seesaw” must be avoid.

Form 4-3-1

Step	Operation	Display	Note
1	Press 【Test】	S-CodE	Enter Password
2	Press 【111111】	S- - - - -	Password is fixed“111111”
3	Press 【Enter】	tESt 0	Select function category”0” to check each load cell ISN
4	Press 【Enter】	dd 01	ENTER the load cell ISN which is going to check
5	Press 【0】 【1】	dd 01	
6	Press 【Enter】	E*****.	Display ISN for No.01 load cell. The ISN= Load cell ISN* corner coefficient
7	Press 【Enter】	dd 02	Display ISN for no.02 load cell

8	Press 【Enter】		
9	Press 【Enter】	tEst 0	Testing Main Interface

Note: Step6: Press **【Gross/Net】** can select to check the ISN without scale itself **【*.*.*.*.*.*.】** or ISN with scale itself **【*****.】** , For example: When the scale is no load, the load cell ISN is 500, then the ISN without scale itself will display 0.

Section IV Corner-difference correction

After scale platform is horizontal and loaded solid by heavy truck, corner-difference correction shall be started. Indicator has two methods of automatical correction and manual correction.

One, Automatical corner difference correction

Operation method is as follows :

Table 4-4-1

Step	Operation	Display	Note
1	Press 【Corner】	C000000	Input calibration password (calibration switch should be on)
	Press 【888888】	C- - - - -	Initial password is“888888”
2	Press 【Enter】	ACty 0	Select function category no. 0 to enter into automatic corner error correction
3	Press 【Enter】	noLoAd	Confirm zero position , at the moment there should be nothing on scale, wait stable indication lights and then press 【ENTER】
4		--- dCr **	Reading the data of stable scale. Put heavy weight on one corner, indicator will display the address for the load cell **
5	Press 【Enter】	--- PASS dCr **	Reading the data of stable scale. Confirmed all of the load cell weighing data. Put heavy weight on another corner, indicator will display the address for the load cell **
5	---	---	---
6		End Weighing Status	Automatic Corner difference correction

Note : Step 3 : If display **【Err 17】** , it means the load cell number do not meet the requirement of auto corner difference correction or the load cell is error.

Step 4 : Display [---] means it is reading the stable data, if it can not read the data within 25 seconds,it will display [ctnu 0]

Enter 0 : Cancel the current operation and return to the weighing status directly.

Enter 1 : Read stable data again.

Enter 2 : Consider the current readed data as the stable data

Step 7 : When all the load cell has been pressed, the indicator will calculate the corner coefficient automatically. If the corner coefficient is abnormal (>1.5 or <0.5), it

will display [Err 30] , please check all the corner coefficient and adjust the scale platform.

Two、Axle corner difference correction function

When doing corner difference correction for the weighbridge, as there is no condition for pressing each corner, the following temporary method can be adopt for adjustment:

Axle type full automatic corner difference correction requires the load cell address should be linked as axle method. The first axle corresponding address is 01, 02; the second axle corresponding load cell address is 03, 04; and so on (see following drawing)



Note1: first adjust the scale platform to be horizontal. At this time, it can be done by checking each load cell ISN; In the normal condition, when scale is no load, the axle direction INS should be near to each other. The load cells under the platform should not be apparently “seesaw”.

Note 2 : When doing axle corner difference correction, if there is no single axle equipment, the double axle vechile can also be used. The follwing conditions should be met:

- (1) The range between the front axle and back axle should not exceed to one section length of platform
- (2) The vechile total weight is better to be more than 10ton. If it is not enough then loading weight on the vechile;
- (3) The weight is better to incline to one axle apparently, for example the back axle;

The corner pressing steps are: vechile first press axle by one certain direction and then change direction and drive on the scale to press the last axle that has not been pressed like the third acle as the following picture

Step 1、Press axle 1 : Step 2、Press axle 2: Step 3、Vechicle change directionand drive on the scale to press the axle 3.




Table 4-4-2 axle corner adjustment

Step	Operation	Display	Note
------	-----------	---------	------

1	Press 【Corner】	C-CodE	Enter Calibration password (Calibration switch has pressed)
	Press 【888888】	C- - - - -	The default password“888888”
2	Press 【Enter】	ACty 3	Select function category no. 3 to enter into automatic axle corner error correction
3	Press 【Enter】	noLoAd	Confirm zero position , at the moment there should be nothing on scale, wait stable indication lights and then press 【ENTER】
4		--- dCr **	Reading scale stable data **Press the weight on one axle, indicator display the pressed load cell axle number
5	Press 【Enter】	--- PASS dCr **	Reading the scale stable data Confirmed all the load cell weighing data. Press heavy weight on another axle, indicator will display the pressed load cell axle number **.
5	---	---	---
6		End Weighing status.	Automatic corner difference correction complete

Note : Step 3 : If display **【Err 17】** , it means the load cell number do not meet the requirement of auto corner difference correction or the load cell is error.

Step 4 : Display [---] means it is reading the stable data, if it can not read the data within 5 seconds,it will display [ctnu 0]

Enter 0 : Cancel the current operation and return to the weighing status directly.

Enter 1 : Read stable data again.

Enter 2 : Consider the current readed data as the stable data

Step 7 : When all the load cell has been pressed, the indicator will calculate the corner coefficient automatically. If the corner coefficient is abnormal (>1.5 or <0.5), it will display **【Err 30】** , please check all the corner coefficient and adjust the scale platform.

Three、Enter weight for corner difference correction

Step	Operation	Display	Note
1	Press 【Corner】	ACty 0	
2	Press 【1】	ACty 1	select function category number 1 to enter into direct input weight value for corner difference correction.
3	Press 【Enter】	AdJ **	** stands for the current pressing load cell weight
4	Press 【 ideal weight value】	--- o***** o weight value	Reading the stable data Reading current weight value correct to idea weight value.
5	Press 【Enter】	PASS Weighing	Setting complete and return to weighing interface.

		staus	
--	--	-------	--

Note : Step 3 : Can enter the corner that the user want to correct. If the weight is pressing between 1 and 2 then can enter 1 or 2 manually to confirm which corner want to correct. If load cell number is less than two or load cell address error, indicator will display 【Err 17】

Four、Enter corner coefficient for corner difference correction.

Step	Operation	Display	Note
1	Press 【Corner】	ACty 0	
2	Press 【2】	ACty 2	Select function category no. 2 to enter to input corner efficient.
3	Press 【Enter】	SAdJ 01	Set No. ** corner difference effieicent directly
3	Press 【0】 【1】	SAdJ 01	For example as set no. 1 corner difference efficient
4	Press 【Enter】	*.*****	No. 01 corner difference efficient.
5	Press 【100120】	1.00120	Correct No. 01 corner difference coefficient.
6	Press 【Enter】	SAdJ **	Correct the other load cells corner difference coefficient one by one

Note : Step 5: when indicator releasing from factory the corner difference coefficient is 1.00000。 Note : Manual input corner difference coefficient is 0.5~1.5。 (The corner difference coefficient is more differet from 1.00000 than the scale installation condition is worse) .

Chapter V. Calibration

1. Calibration

Put calibration switch on the calibration position, do calibration as following table.

Table 5-1-1

Step	operation	display	Notes
1	press 【calibration】	C-CodE	need to press calibration button
2	Press 【888888】	C*****	input calibration password, the delivery default password is “ 888888”
3	press 【input】	E ***	display the current division
4	Press 【↔or→】	E 10	Input division: 1/2/5/10/20/50/100 can be selected, e.g.: 10
5	press 【input】	dC *	The current decimal point number (after decimal point changed, it will delete all weighing records automatically)
6	Press 【0】	dC 0	input decimal point number (0-3) , for example: no decimal point 0 (note 5-1-0)
7	press 【input】	【Pn VWXYZ】	display system parameter V : application W: zero-setting range in N.W X : zero tracing range Y : manual zero setting range Z : 13455 power-on zero setting range (note 5-1-1)

8	Press【13455】	Pn13455	input system parameter
9	Press【input】	FLt *	display display current filter parameter range 0-4 , number more bigger and filter strength more stronger
10	Press 【2】	FLt 2	Input current filter parameter, e.g.2
11	Press【input】	F*****	Display full scale capacity, overloading alarming value= full scale +9*E
12	Press 【05000 0】	F050000	input full scale value
13	Press【input】	noLoAd	Zero confirmation, there is nothing on the scale, after indication light is bright, press 【input】 , press 【á】 take current zero as zero, and skip to the first loading point to operate
14	Press【input】	--- ALoAd 1	reading stable data calibrate the first loading point
15	press 【01000 0】	A010000	Load weights until stable indication light is bright, input the real weight of weights on the scale. For example: 10000 Press 【check】 calibrate the first loading point and enter to step 10 multi-point calibration; Press 【F1】 can check ISN “ 1000.” Of related empty scale Press 【input】 , two points calibration is finished and quit to weighing interface
16	press 【check】	--- ALoAd 2	reading stable data calibrate the second loading point
16	Press【20000】	A020000	Load weights until stable indication light is bright, input the real weight of weights on the scale. For example: 20000
17	press【input】	End Weighing status	calibration is finished

Note: step 7: Pn parameter set method

Pn parameter, meaning of every bit and parameter range please see table 5-1-2、5-1-3、5-1-4、5-1-5、5-1-6

(table 5-1-2)

Value of V	-
application	

(table 5-1-3)

Value of W	0	1	2	3
zero setting in net weight	Not use	1e	2e	3e

If current indicator status accord to zero setting range in net weight, then indicator quit net weight status, and set zero. Otherwise display [Err 19]

(table 5-1-4)

Value of X	0	1	2	3	4	5	6	7	8	9
zero tracing range	Not trace	0.5e	1.0e	1.5e	2.0e	2.5e	3.0e	3.5e	4.0e	4.5e

(table 5-1-5)

Value of Y	0	1	2	3	4	5
Press 【set zero】 button, zero setting range	0%F.S	2%F.S	4%F.S	10%F.S	20%F.S	100%F.S

(table 5-1-6)

Value of Z	0	1	2	3	4	5
Switch on zero setting range	0%F.S	2%F.S	4%F.S	10%F.S	20%F.S	100%F.S

2. Division auto switch and calibrate linearity

Table 5-2-1

step	operation	display	Notes
1	press 【set】	PSt 00	need to open calibration switch
	Press 【input】	C-CodE	
2	Press 【888888】	C- - - - -	input calibration password, default password is “888888”
3	Press 【input】	E 10	Display the current division, press 【↔or→】 to select division 1、2、5、10、20、50 and 100
4	press 【input】	dC 0	Current decimal point number (0~3) (after decimal point changed, it will delete all weighing records and vehicle number tare weight)
5	Press 【input】	【Pn VWXYZ】	display system parameter V : application W : set zero range in net weight X : zero tracing range Y : manual set zero range Z : 13455 power-on set zero range, e.g. 13455
6	Press 【13455】	Pn13455	input system parameter
7	Press 【input】	FLt 2	Display current filter parameter range 0~4 , number more bigger and filter strength more stronger
8	Press 【input】	F030000	Display full scale capacity, overloading alarming value= full scale +9*E
9	Press 【input】	n*****	division value switch point 1
10	Press 【0】	n000000	For example:000000 (not use division value switch function)
11	Press 【input】	h*****	division value switch point 2
12	Press 【0】	h000000	For example:000000 (not use division value 2 switch function)
13	press 【input】 press 【↓】 press 【↓】 press 【↓】 press 【↓】 press 【↓】	A ***** L ***** Lh***** b ***** o***** oh*****	Display calibration parameter, not change it randomly: if not to check, can press 【weigh】 button to quit calibration status, press 【↓】 button not save current operation interface input value. (when change indicator, can input data directly, no need calibrate again) specification : A : zero AD code L、LH : the first calibration rate b : the first phase demarcation point AD code o、oH : the second calibration rate
14		Weight status	parameter setting is finishe

Note: Step 9 to 12: indicator supplies three phase division auto switch function. Can set two division switch point: when gross weight is smaller than division switch point 1, display division downward switch 1 grade (for example: 50 switch to 20, 10 switch to 5); when gross weight is bigger than division switch point 2, display division upward switch 1 grade (for example: 1 switch to 2, 5 switch to 10). Switch point set as “000000”, means not use related switch function. When division is 1, it can not switch division downward.

Note: Step 6: if not do the second phase calibration, then the demarcation point AD code of the first phase is symbol number 9999999, the AD code is (load cell ISN*10) +1000000

Chapter IV. Other Operation

1. Date and time setting

step	operation	display	Notes
1	press [lock]	d12.05.13	display current date
2	press [number button]	d12.05.13	change date
3	Press [120515]	d12.05.15	input the correct date
4	press [input]	d09.08.15	display current date
5	Press [input]	t12.53.48	note: after timing switch-off function starts, can not change date any more
6	press [number button]	t12.53.30	display current time
7	Press [125345]	t12.53.45	input correct time
8	press [input]	t12.53.45	display current time

2. Calibration password management

Password management includes add-password selection, password change and random code unlock (table 6-2-1)

Steps	Operation	Display	Explanation
1	press [setting]	PSt 00	calibration switch should be open
2	press [2] [0]	PSt 20	select parameter/function category 20, setting modification of calibration password
3	press [ENTER]	C-CodE	input calibration password
4	press [888888]	C- - - - -	Eg. 888888
5	press [ENTER]	n-CodE	input new calibration password
6	press [123456]	n-----	Eg.123456
7	press [ENTER]	r-CodE	Re-input calibration password
8	press [123456]	r-----	Eg.123456
9	press [ENTER]	PASS Back to status of weighing	modification is successful, back to status of weighing

Note : Step 5 : In order to ensure the newly input password correct, it is required to input the new password again. If the password that input in two times are same then password is modified successfully. After display **[PASS]** it automatically returns to the weighing status. If the password that input in two times are different then back to the step 5 asking to input the new Password

- After one-time password of calibration is input into indicator, not need to input password of calibration; but password of calibration must be input again when indicator re-start or modify password.

6.3 Timing Off

①、The way to set the expire date of probation

Steps	Operation	Display	Explanation
1	Press 【set】	PSt 00	
2	Press 【21】	PSt 21	Select Parameter/Function category no. 21 to enter timing off setting
3	Press 【ENTER】	C-CodE	input calibration password
4	Press 【888888】	C- - - - -	Eg: 888888
5	Press 【ENTER】	d**.**.**	indicating current date
6	Press 【090428】	d12.04.28	Input expire date Eg: 12/04/28
7		Weighing status	Setting is finished

②、Remove and modify the timing off:

- 1) After exceeding the set off time, the indicator will display **【Err 26】** and can not weigh
- 2) If want to cancel timing off, only need to set the date of timing off as 99.99.99

6.4 Cancel password of calibration temporarily

This function is adopted when the password is lost or forgotten. You may use following methods to get the temporary password and use it to do some operation like unlock, calibration etc. Details is shown as follows:

- 1). Follow table 6-2-2 to process step by step;
- 2). Phone sales service number of our company (On the back cover of the manual) and tell the random code to our technical service people to get a temporary password.

Refer to table 6-2-2

Steps	Operation	Display	Explanation
1	Press 【set】	PSt 00	
2	Press 【22】	PSt 22	Select Parameter/Function category no. 22 to check the random code
3	Press 【ENTER】	S-CodE	input setting password
4	Press 【111111】	S- - - - -	Input password“111111” (invariable)
5	Press 【ENTER】	r*****	tell these 6-digit number to our sales people, awaiting decode, re-press 【enter】
6	Press 【ENTER】	L*****	input decode
7	Press 【ENTER】	PASS Weighing status	, decoded successfully, if failed, indicating Err 16

6.5 The way to set the expire date of probation

①、setting the expire date of probation

Steps	Operation	Display	Explanation
1	Press 【set】	PSt 00	
2	Press 【23】	PSt 23	Select Parameter/Function category no. 23 to

			enter setting the expire date of probation
3	Press 【ENTER】	d-CodE	input password of timing off
4	Press 【888888】	d- - - - -	Eg. 888888
5	Press 【ENTER】	d**.**.**	indicating current date of off
6	Press 【090428】	d12.04.28	Input date of off, eg 12/04/28
7		Weighing status	Setting is finished

Note : step 4 : Adopt function of expire date of probation, date can not modified again, cancel date of timing off when set date of timing off as 99.99.99.

②、Remove and modify expire date of probation

- 1) After exceeding the set expire date, the indicator will display **【Err 27】** and can not weigh
- 2) If want to cancel timing off, only need to set the probation time to 99.99.99

③、Setting password of expire date

Steps	Operation	Display	Explanation
1	Press 【set】	PSt 00	
2	Press 【33】	PSt 33	Select Parameter/Function category no. 33 to enter setting the expire date of probation
3	Press 【ENTER】	d-CodE	input password of timing off
4	按 【888888】	d- - - - -	eg888888 (invariable)
5	Press 【ENTER】	n000000	input new password of calibration
6	Press 【111111】	n111111	eg111111
7	Press 【ENTER】	r000000	re-input new password of calibration
8	Press 【111111】	r111111	eg111111
9	Press 【ENTER】	Weighing status	Setting is finished

④、Randomly cancel date of probation

This function is adopted when the password of expire date of probation is lost or forgotten. You may use following methods to initialize password of expire date of probation (888888, and probational expiry date (999999)

Steps	Operation	Display	Explanation
1	Press 【set】	PSt 00	
2	Press 【34】	PSt 34	Select Parameter/Function category no. 34 to check random ISN
3	Press 【ENTER】	S-CodE	input setting password
4	Press 【111111】	S- - - - -	Input password“111111” (invariable)
5	Press 【ENTER】	r*****	tell these 6-digit number to our sales people, awaiting decode, re-press 【enter】
6	Press 【ENTER】	L*****	input decode
7	Press 【ENTER】	PASS Weighing status	decoded successfully, if failed, indicating Err 16

6.6 System testing

①、checking ISN of each corner

。 In order to ensure accuracy of amend corner coefficient and stability of weighing scale, digital weighing system has the same requirement of stable base and proper mechanical installation as analog weighing system, keeping balance of weighing platform is very important.

Checking ISN of each corner to benefit to adjust weighing platform 。 Refer to method of table 4-3-1

Platform with proper installation, ISN of corner should be equal more or less on the same axle, ISN of 1,2,6,5 is equal more or less, ISN of No.3,4 is equal more or less. table 4-3-1

Steps	Operation	Display	Explanation
1	Press 【set】	S-CodE	input password of testing
2	Press 【111111】	S- - - - -	invariable“111111”
3	Press 【ENTER】	tEst 0	select type No. 0of testing, checking ISN of each load cell
4	Press 【ENTER】	dd 01	Input No. of each load cell
5	Press 【0】 【1】	dd 01	
6	Press 【ENTER】	E*****.	Display ISN of No.01 load cell , ISN=ISN of load cell*coefficient
7	Press 【ENTER】	dd 02	Display ISN of No.02 load cell
8	Press 【ENTER】		
9	Press 【ENTER】	tEst 0	testing master interface

Note : step 6 : press **【 gross/net 】** checking ISN of weighing scale unload **【*.*.*.*.*.】** ISN with load **【*****.】** , eg : ISN of load cell is 500 with load , ISN of load cell is 0 unload.

②、Check overloading record

D20 can automatically save the top 6-group overloading record

The overloading record will be cleaned up after calibration is successfully done. The overloading record can not be manually cleaned up. Press **【table】** , **【70】** to print out overloading record.

Steps	Operation	Display	Explanation
1	press 【check】	S-CodE	input password of testing
2	Press 【111111】	S- - - - -	invariable“111111”
3	Press 【ENTER】	tEst 00	select type of testing
4	press 【1】	tEst 01	select type of testing : 1 、 checking record of overloading
5	Press 【ENTER】	no 01	Display record serial no.
6	Press 【ENTER】	d*.*.*.*	Display the overloading date
7	Press 【ENTER】	t*.*.*.*	Display the overloading time
8	Press 【ENTER】	*****	Display the actual data of overloading(don't indicate decimal)
9	Press 【ENTER】	no 02	Display the next record
.....			
10	Press 【ENTER】	End	Record display is finished

③、Check total internal code

each load cell internal code plus are the total internal code.

Proce dure	operate	display	annotation
1	press 【2】	tEst 02	Choose functional category number 2 enter into total internal code
2	press 【input】	1123.	display total internal code
3	press 【input】	tEst 00	

Note : Procedure 2 : press **【gross/net】** Can choose to check the internal code when remove the empty balance **【*****】** or not to remove the empty balance **【*****】**.

④、Check check program configuration and version number

Proce dure	operate	display	annotation
1	press 【3】	tEst 03	Choose functional category number 3 enter into the viewer configuration and version number
2	press 【input】	A 01-C	Program configuration and version information
3	press 【input】	tEst 00	

Note : Procedure 2 : Display content

Display digits (from left to right)	1	2	3	4	5	6	7
meaning	A: without the panel micro print P : Thermal panel micro print P1: Needle panel micro print		Version number		Custom agreement Routine is to display ‘-’	E: English print C: Chinese print	No: Instrument not encryption ; 1: Instrument encrypted.

⑤、Check the last calibration zero for each sensor internal code value

when calibrating the zero point , automatic save each sensor internal code vauue on the empty balance empty balance, in the future weighing platform for maintenance of the sensor by checking the air balance internal code and the current each sensor empty balance internal code value change to analyze how to maintenance. If not calibrate the zero point, the value will be invalid.

Proce dure	Operate	Display	Annotation
1	press 【4】	tEst 04	Choose functional category number 4 enter into the original calibration zero for each sensor internal code
2	press 【input】	rAd 01	Input the sensor number that you want to check
3	press 【input】	*****.	Display the number sensor internal code
4	Press 【input】	rAd 02	Display the number 2 sensor internal codeForward view such as : rAd 02


.....			
-------	-------	-------	-------

⑥、Check the battery voltage

Proce dure	Operate	Display	Annotation
1	press 【5】	tEst 05	Choose functional category number 5 enter tp check the battery voltage
2	press 【input】	U 11.9	11.9 Said the battery voltage is 11.9V
3	press 【input】	tEst 00	

⑦、Check the key function and instrument PC interface RS232 communication

function



Proce dure	Operate	Display	Annotation
1	Press 【testing】	tEst 00	enter into the test interface according to table 6-3-1
	press 【8】	tEst 08	Choose the functional category number 8 and check the key and instrument PC interface RS232 communication
2	press 【input】	t ** r ##	** Said the key value that press, and at the same time the instrument send out this value from the feet 2 of PC from the PC interface. ## Said the value that the instrument PC interface 3 feet received, if not will display [— —]。 If the above two values are the same, show that the RS232 interface normal. When there is no button **display [— —] , If the serial accept sending and receiving is normal ##display[88]。
3	press 【weigh】	Weighing interface	

⑧、Calibrate RS232/4~20mAOutput converter function interface



Proce	Operate	Display	Annotation
-------	---------	---------	------------

dure			
1	press【test】	tEst 00	enter into the test interface according to table 6-3-1
	press【9】	tEst 09	Choose functional category number 9(Need to open the calibration switch , or display Err 91)
2	press【input】	T000000	The serial port RS232output.0000000=.0000000=..... at this time calibrate the zero point on the converter , So the display value output is 0mA
3	press【100000】	T100000	The serial port RS232output.0000010=.0000010=..... at this time calibrate the full capacity on the converter , the display is 100000 output is 20mA
3	press【weigh】	weigh interface	

Adapter 7 PC Communication parameter Settings

Proce dure	Operate	Display	Annotation
1	press【setting】	PSt 00	
	press【1】	PSt 01	Input parameter/functional category number“01”
2	press【input】	Adr ***	Display the current address (instruction way to effective)
3	press【1】	Adr 001	Communication address (1-255) choose the 001
4	press【input】	bt 600	Serial communication baud rate
	press【←or→】	bt 9600	Optional baud rate 600、1200、2400、4800、9600 和 19200bps. Choose 9600
5	press【input】	tF *	Show the current way of communication
	press【0】	tF 0	Communication mode selection. Choose 0 Mode selection range : 0-8 , Specific see appendix A
6	press【input】	Jn ****	The current check way
	press【←or→】	Jn nonE	Check mode selection , Options are as follows: choose nonE nonE : No check ; odd Odd parity ; EvEn : even parity check ; mArk : mark ; SPAcE : space ;
7	press【input】	weighing status	

Adapter eight save printing parameter Settings

Proce dure	Operate	Display	Annotation
1	press【setting】	PSt 00	Input parameter/functional category number
2	press【2】	PSt 02	Choose parameter/functional category number heung into storage printing parameter Settings
3	press【input】	S-CodE	Please enter the password Settings
4	press【11111111】	S- - - - -	Enter Password“111111” (retaining)
5	press【input】	AUto 0	The current automatic printing (0-2) 0 : Manual printing ; 1 : Automatic printing (Keep off automatic printing condition) ; 2 : Automatic printing (shutdown didn't keep automatic printing state).
6	press【input】	tyPE 1	The current printer types (0-3) choose :

			0 : Print invalid ; 1 : Panel micro play Chinese characters ; 2 : EPSON LQ-300K (+) 、 LQ1600K、 DS-300、 松下 KX-P1131 ; 3 : panasonic KX-P1121 4 : POS58
7	press 【input】	hL 50	The current print back to zero limit choice , such as : 25 : Return the full amount 25% After weighing the following can print ;
8	press 【input】	Arr 1	The current number of forms (1-4) 1 to 4 represent the 1 and 4 bill
9	press 【input】	L000200	The current automatic print the minimum weight limit is greater than the automatic printing 200
10	press 【input】	b 03	The current forms printing on paper line number (0-99)
11	press 【input】	odE 01	Print format selection (0-9) Zero: record format 1: vertical duplicate format; 2: transverse single format 3: custom record format; 4: custom vertical duplicate format 5: custom transverse single format; 6: filling type; 7: micro DaHeng duplicate format; 8: micro hit record format; 9: micro play custom transverse single format. 10: custom filling type;
12	Press 【input】	uo 1	If the car use: 0: no use; 1: use (when not in use car number 0)
13	Press 【input】	uhn 1	Whether to use the article number: 0: no use; 1: use (when not in use article number 0)
14	Press 【input】	So 1	Storage is the input of the car : 0 : Don't input (Direct call the current car number) ; 1 : input
15	Press 【input】	Shn 1	Storage is input article no : 0 : Don't input (Direct call the current car number) ; 1 : input
16	Press 【input】	ut 0	Unit of weight selection (0-1) : 0 = kg ; 1 = t。
17	Press 【input】	Print 1	Store the current weighing record whether print 0 : Don't print , 1 : print。
18	Press 【input】	PAbc 0	(spare)
19	Press 【input】	do 00	Print out a set of data after printer automatic feed line number and print on paper line number (Mainly used for convenient tearing)

Section 9 Custom infill pounds single set

1. Set print content: each set print content, and the specific meaning of the parameters is set up as follows :

00 : don't print 01 : serial no 02 : date 03 : time 04 : car no
05 : cargo no 06 : gross weight 07 : tare 08 : Net weight
09 : client
10 : remark 11 : Empty fill 12: Empty fill 13 : Empty fill (Only when effective filling format)

2.Setting methods:

▲ Custom filling type including setting print content and print margin, setting the print

content method

According to the pounds single content requirements setting the print content specific operation as follows:


Procedure	Operate	Display	Annotation
0		【xxxxxx】	Weighing status
1	Press 【Setting】	PSt 00	Input parameter/functional category number
2	press 【1】【6】	PSt 16	16 : Custom fill the contents of the format
3	press 【input】	S-CodE	input the setting password
4	press 【111111】	C111111	input password, press 111111(fixed)
5	press 【input】	CL0 01	Enter the first line print content
6	press 【input】	CL1 **	Input the second line print content
...	...	...	...
7	press 【input】	CLE **	Input line 14 printed content
8	press 【input】	Weighing status	Setting end exit to the weighing status

Note :1: This instrument support 15 done custom format input ;

2.:15 Done content must set, such as don't print please set to 00, the meter will skip this column (line) contents of print (print not appear blank line); Such as playing blank lines are input 13

The Head of the table length

PH=30.40mm



The
spacing

过磅单 WEIGHT BILL	
第 1 联司磅员留存 Operator	
序号 SERIAL No.	123
日期 DATE	2012-05-30
时间 TIME	12 .35 .28
车号 VEHICLE No.	00001
货号 CARGO No.	orange
总重 GROSS	1580 kg
皮重 TARE	80 kg
扣率 DISCOUNT	10 %
净重 NET	1350 kg
客户 CUSTOMER	宁波贸易公司
备注 REMARK	Zhangsan


PG=7.82mm

The zeroth line
number CL0=01

The first line number
CL1=02

The end of the table length

PE=22.60mm



PG=94.00mm

Next, set print margins: use the rule to measure the length of PH、PG (Total print width divided by the number of lines)、PE、PA、PB (See figure 6-7-1) , entre and print 。 According to the results of PE, PF printing, adjustment of these parameters, so that the content can play in the corresponding position.

step	operate	display	explanation
0		【xxxxxx】	Weighing state
1	press 【set】	PST 00	Selection of parameters / Functional category number
2	press 【1】 , 【7】	PST 17	17: Enter custom fill print margin settings
3	press 【entre】	S-CodE	Pls entre testing password
4	press 【11111】	S- - - - -	entre password 11111
5	press 【entre】	Ph xx.xx	entre thelength of the table head。
6	press 【3040】	Ph 30.40	Eg. PH=30.40mm, See Appendix : Filling type List
7	press 【entre】	PG xx.xx	entreThe line spacing。
8	press 【0782】	PG 07.82	Eg. PG=7.82mm, See Appendix : Filling type List
9	press 【entre】	PE xx.xx	entre the length of the table end
10	press 【 0226】	PE 22.60	Eg. PE=22.60mm, See Appendix : Filling type List
11	press 【entre】	PA xx.xx	entre Left margin of thelist.
12	press 【 4100】	PA 41.00	Eg. PA=41.00mm, See Appendix : Filling type List
13	press 【entre】	Pb xx.xx	entre the width of the list.
14	press 【 9400】	Pb 94.00	Eg. Pb=94.00mm, See Appendix : Filling type List
15	press 【entre】	PF xxxx	entrePaper trimming.
16	press 【 0000】	PF 0000	Eg. PU=0000, after multiple pages of paper, if there is a deviation, we can through it into the first point. Length=0.14mm
17	press 【entre】	Weighing interface	

Section 10. The initialization function

This interface includes all parameter initialization , Now an initialization angle difference coefficient operation shows as below , The rest of the operation is the same as this one.

step	operate	display	explanation
1	press 【F1】	C-CodE	entre calibration password (turn on the calibration switch)
2	press 【888888】	C- - - - -	Factory initial password “888888”
3	press 【enter】	rEst 0	Select function category number 0, Enter the initial angle difference coefficient. 1、 Initialization of communication parameters 2、 Initialization of print parameters 3、 Initialization of the custom print parameters and the license plate number 4、 Initialization of calibration parameters 5、 Initialization of the Weighing records and wagon tare 9、 Initialization of all the above parameters.
4	press 【0】	rEst 0	Eg.0 , Initialzation Coefficient of angle differenc and the number of types of sensor communication.
5	press 【enter】	SurE 0	Confirmation interface
6	press 【1】	SurE 1	Confirmation operate。 0: no initialization , and back to Weighing interface 1: Initialize。
7	press 【enter】	----- End weighing interface	Initializing Initialization over Check result and return to the weighing interface or restart

Section 11. Print tone scale parameter

step	operate	display	explanation
1	press 【reprot form】	Pb 00	
2	press 【80】	Pb 80	entre“80” , Choose tone scale parameter print
3	press 【enter】	Print	Start printing, when print is finished, go back to weighing state automaticly

Section 12. Set print company name

(1) . Summary

- 1 . This indicator can input Chinese characters location code or according 《**Letter and number code**》 entre Print content
- 2 . This indicator can save 20 model name , which contain letter and number. (one Chinese word takes two space of one letter.

(2) . Entre mode

1. entre rules :

- ▲ ! According the indicator attached letter and number enter code to enter the letters (with number) 。 The specific code as shown in table 6-12-1 《letter and number code》 。
- ▲ ! In order to distinguish between Chinese characters and letters, The top two bits are not all "0" for Chinese characters , The top two bits are both "0" for a letter or a number , The four bits are all "0" for the end.
- ▲ ! Text enter has two ending ways , One is the end of nature to send over 20 letters , Another is the text required letters less than 20 letters, ending with "0000".
- ▲ ! The input information is stored only at the end , press 【weigh】 to quit in the halfway and the input information is not saved.
- ▲ ! In the information input state,. , The top two bits (instrument to the left side of two) displays the current entre position (1 letter occupies the 0.5 position).
- ▲ ! The printed output is right-justified , If it needs to align left or center , it has to add corresponding number of letters and number code spaces at the end. , that is "0001"

Letter and number code 6-12-1

cod e	characte r	cod e	characte r	cod e	characte r	cod e	characte r	cod e	characte r
01		21	4	41	H	61	\	81	p
02	!	22	5	42	I	62	]	82	q
03	"	23	6	43	J	63	^	83	r
04	#	24	7	44	K	64	-	84	s
05	\$	25	8	45	L	65	'	85	t
06	%	26	9	46	M	66	a	86	u
07	&	27	:	47	N	67	b	87	v
08	'	28	;	48	O	68	c	88	w
09	(	29	<	49	P	69	d	89	x
10	)	30	=	50	Q	70	e	90	y
11	*	31	>	51	R	71	f	91	z
12	+	32	?	52	S	72	g	92	{
13	,	33	@	53	T	73	h	93	
14	-	34	A	54	U	74	i	94	}
15	.	35	B	55	V	75	j	95	~
16	/	36	C	56	W	76	k		
17	0	37	D	57	X	77	l		
18	1	38	E	58	Y	78	m		
19	2	39	F	59	Z	79	n		
20	3	40	G	60	[	80	o		

(3) . The specific operation


For example "1992 中国煤厂"

step	operate	Display in the weighing condition	Explanation of parameters / functional categories
1	press 【set】	PSt 00	
2	press 【13】	PSt 13	entre13 set company name
3	press 【entre 】	0.0 0000	Entre code
4	press 【18】	0.0 0018	accoding 6-12-1, entre the code of "1": "18"
5	press 【entre 】	0.5 0000	Entre code

6	press 【26】	0.5 0026	According 6-12-1entre the code of “9”：“26”
7	press 【entre 】	1.0 0000	Entre code
8	press 【26】	1.0 0026	According 6-12-1entre the code of “9”：“26”
9	press 【entre 】	1.5 0000	Entre code
10	press 【19】	1.5 0026	accoding 6-12-1entre the code of “2”：“19”
11	press 【entre 】	2.0 0000	Entre code
12	press 【5448】	2.0 5448	Accoding Location code list, entre the code of “中”：“5448”
13	press 【entre 】	3.0 0000	Entre code
14	press 【2590】	3.0 2590	Accoding Location code list, entre the code of “国”：“2590”
15	press 【entre 】	4.0 0000	Entre code
16	press 【3526】	4.0 3526	Accoding Location code list, entre the code of “煤”：“3526”
17	press 【entre 】	5.0 0000	Entre code
18	press 【1907】	5.0 1907	Accoding Location code list, entre the code of “厂”：“1907”
19	press 【entre 】	6.0 0000	Entre 0000 finish
20	press 【weigh 】	Weighing state	Complete all the input content, return the weight state


Chapter 7 Hardware introduction

7.1 Whole Structure for indicator



Front view

Inside view for front shell



1A Fuse inside

Calibration key: power on self test, according to a will allow calibration operation or modify the calibration parameters

Switching power supply 15 v power supply interface


Battery power supply interface

mainborrd

Back view

Inside view for back shell


7.2 Mainboard introduction




RS232 chip (MAX202 or SP232EEP) : when the computer can't get the instrument data, or a big screen using RS232 way no signal, can through the following two ways to check: 1, the fifth chapter 6 day the first seven check this core place is good or bad. 2, then test it according to the left drawing.

In normal weighing instrument, using a multimeter to communication and v test can have 2 v above unstable change; In the dc and v down test type there will be changes of positive and negative voltage (> 2 v)



8	17	16	15	14	13	12	11
15	14	13	12	11	10	9	



7.3 Introduction for Site Electric



or



Indicator internal electrical isolation ($< 3 \text{ kv}$).
Indicator internal isolation design reason: because of the various peripherals grounding, power supply and leakage, which has resulted in these peripherals and sensor between electrical or big or small voltage difference, light person damage these corresponding peripheral interface, print messy code and communication error, the person that weigh for damage digital sensor, damage bus equipment



Chapter 8 Information tips

8.1 Normal information tips :

No.	Display	Notes
1	【 ----- 】	Please wait a moment, indicator internal operations, don't make any operation
2	【 Print 】	Indicator is to printer transmission data.
3	【 Load 】	The first two weighing data storage.
4	【 End 】	end of operation
5	【 PASS 】	Modify Settings success
6	【Lo bAt】	Low power, the instrument will be shut down.
7	【 - 】	Battery voltage is lower than 10.2 V please promptly to the battery charge
8	【 SAve 】	Data saving

8.2 Wrong information tips

No.	Display	Notes
1	【Err 03 】	Overload alarm shall be discharged immediately all or part of the load
2	【Err 08 】	This condition no record
3	【Err 11 】	Car number storage is full, please delete part or all of the memory tare.
4	【Err 12 】	Can't use micro play or POS machine to print it
5	【Err 13 】	Parameter/functional category selection is not correct
6	【Err 16 】	A password is not correct
7	【Err 17 】	Parameter setting is not in conformity with the requirements, please refer to the relevant parameters of the input range of requirements
8	【Err 18 】	Weighing platform linear calibration, the calibration weight less than the calibration weights
9	【Err 19 】	Zero and negative weighing or unstable cannot print, do not satisfy the reset condition not print; Storage input parameters not adhesion requirements; Discrepancy zero conditions; Do not conform to the peeling condition: unstable, negative; Call no weight information of the car
10	【Err 23 】	Memory U10 damage, please repair
11	【Err 26 】	Calibration timing shutdown time
12	【Err 28 】	Print date less than already stored weighing record date
13	【Err 30 】	Automatic or manual Angle difference adjusted abnormal results
14	【Ecc 01~16 】	No. n loadcell communication error
15	【EccP 01~16 】	No. n Digital loadcell communication encryption not consistent
16	【ErrP 】	Printer connection error, printer error or printer didn't paper, please add paper or by weighing key exit
17	【Err 91 】	Please press the instrument at the back of the "calibration button" (after the boot in a can)

8.3 Other information tips

No.	Display	Notes
1	【Ctun 0 】	Do not gather stable data, can enter 0, 1 or 2, its function is: 0: tell instrument is no longer do this step work, direct return weighing state. Input 1: tell instrument try again. Input 2: tell instrument these not too stable data can be used

2	【--S--】	nstrument is on the zero
3	【S-CodE】	Operation codes "111111"
4	【C-CodE】	Input calibration password

Appendix A: communication protocol

Serial data format can be set to: eight data bits, a stop bit, no (parity) parity bit; Serial communication mode is divided into continuous communication mode and command communication way two kinds, among them, the continuous mode according to the communication protocol format and divided into three; Through the TF parameters to choose can be realized.

(1). Continuous mode (TF = 0) : the transfer of data for instrument display current weight. Each frame data from 12 groups of data. Format are shown below:

Bite X	Content	Note		Example (transmit + 20.00)	
		Content	Code	Cotent	Hex Code
1	Beginning	(XON)	02	XON	02
2	+or-	Sign bit	2B/2D	+	2B
3	Weighing Data	Highest order	30 ~ 39	0	30
4			30 ~ 39	0	30
5			30 ~ 39	2	32
6			30 ~ 39	0	30
7			30 ~ 39	0	30
8		Lowest order	30 ~ 39	0	30
9	Number of decimal	From right to left (0 ~ 4)	30 ~ 34	2	32
10	Verify	High four		Verify = 0x1B	31
11		Low four			'B'
12	End	XOFF	03	XOFF	03

X or = $2 \oplus 3 \oplus \dots \oplus 8 \oplus 9$.

Note 1 : If X or verify high or low four bit: Xor and high,low four digitals lower than or equal to 9, must add 30h, become ASCII code and send , eg:Xor verify higher than 4 digits and it is 6 digits

Sending data ASCII code , for example : Xor verify larger than 4 which is 6, after add 30h, which become 36h, send ASCII code 6 ; Xor high, low 4 bits. If it is bigger than 9, it will add 37h, become ASCII code sending. For example: Xor verify higher than 4 which is B, after adding 37, become 42h which send ASCII code B.

(2) MODBUS order mode (TF=1):

Communication of indicator and upper computer adopt MODBUS.

(3) Continuous mode (TF=2): (compatible D2+)

All data is ASCII code, each frame data forms 8 bytes (contain decimal point), data transfer from low to high-order position. There is a separator between every frame "=", sending data which is weighing value. If weigh data currently display 188.5, continuous send 5.88100=5.88100=..... If weigh data currently display -188.5, continuous send 58810=-.58810=-.....

(4)Continuous mode (TF=3):

All data is ASCII code, each frame data forms 8 bytes (contain decimal point), data transfer from low to high-order position. There is a separator between every frame "=", sending data which is weighing value. If weigh data currently display 188.5, continuous send 5.88100=5.88100=..... If weigh data currently display -188.5, continuous send 58810=-.58810=-.....

(5) Continuous mode (TF=4): (compatible Toledo T800) without checksum

Continuous mode (TF=5): (compatible Toledo T800) with checksum

Every data composite 10 bits, first bit is start bit, tenth bit is stop bit. 8 bits in the middle which is data bit; Continuous output every frame which is 18 bytes.

Continuous output mode 2																	
StX	A	B	C	X	X	X	X	X	X	X	X	X	X	X	X	CR	CKS
1	2			3					4						5		6

Among :

1. <StX> ASCII start character (02H) 。
2. Status words A , B , C 。
3. Displaying weigh, which is gross or net weigh. 6 bits data without symbol and decimal point.
4. Tare weigh, 6 bits data without symbol and decimal point.
5. <CR> ASCII
6. <CR> ASCII return character (ODH) 。
7. <CKS> checksum。

Status word A			
Bits 0 , 1 , 2			
0	1	2	Decimal place
0	0	0	KGKG00
1	0	0	KGKGX0
0	1	0	KGKGKG
1	1	0	KGKGX.X
0	0	1	KGKG.KG
1	0	1	KGX.KGX
0	1	1	KG.KGKG
1	1	1	X.KGKGX
Bits 3 , 4			Division value factor
3	4		
1	0		
0	1		
1	1		
Bit 5			Permanent 1
Bit 6			Permanent 0

Status word B	
Bits	Function
Bit 0	GW = 0 , NW = 1
Bit 1	Sign : positive = 0 , negative = 1
Bit 2	Overload (or smaller than 0) = 1
Bit 3	Condition = 1
Bit 4	Unit: kg = 1
Bit 5	Permanent 1
Bit 6	Indicator in power which display 1

Status word C	
Bit 0	Permanent 0
Bit 1	Permanent 0
Bit 2	Permanent 0
Bit 3	Printing order = 1
Bit 4	Expanding display (X10) = 1
Bit 5	Permanent 1
Bit 6	Permanent 0

(6). Continuous mode (TF=6) : (Chaman8803)

Each byte data 8 bits , check bit is optional, stop bit is 1 bit.


In order to reduce transferring bytes number, status describe by status byte. Data compression becomes three bytes BCD code, a frame data with signal byte FF (HEX) , consist of 5 bytes. FF(HEX) status word BCD1 BCD2 BCD3

Definatin for status word as below:

D7	D6	D5	D4	D3	D2 D1 D0				
Overflow	Stable	Symbol	Unit	GW/NW	Decimal places				
1 overflow	1unstable	1 positive	1 ton	1 GW	000	001	010	011	100
0 normal	0stable	0 negative	0kg	0 NW	X.	.X	.XX	.XXX	.XXXX

(7). Continuous mode (TF=7):

Each byte data are composited by 10 bits. First bit is start bit, tenth is stop bit, 8 bits in the middle which are data bit and parity data;



Header 2

GS (Gross data)

NT (Net data)

TR (Tare data)

(8). continuous mode (TF=8) : (same as HT9800-D7 mode1)

1、Data format for serial communication as below:

10 bit : 1 start bits , 8 data bits , 1 stop bit.

2、Serial communication sends important data which is ASCII code , sending 12 bytes for each time.

Defination as follow :

First byte : start bit (02H)

Second byte : Status word A

Third byte : Status word B

Fourth byte : Status word C

Fifth byte : Weigh value high-order of 6 bits.

Tenth byte : Weigh value low-order of 6 bits.

Eleventh byte : enter (0DH)

Twelveth byte : line feed (0AH)

Status word A

D7	D6	D5	D4	D3	D2	D1	D0
0	0	1	0	0			

Decimal point :

	X	.X	.XX	.XXX	.XXXX	.XXXXX
D2 =	0	0	1	1	1	1
D1 =	0	1	0	0	1	1
D0 =	0	1	0	1	0	1

Status word B

D7	D6	D5	D4	D3	D2	D1	D0
0	0	1	1				0

D3 = Static is 0 , dynamic is 1。

D2= within weighing range is 0, overload is 1.

D1= weigh value positive is 0, negative is 1.

Status word C = 20H

AppendixB : Example weighing record sheet format :

(Standard) Record format :

Weighing record sheet				Date : 2008-03-05		
SERIAL No.	Time	VEHICLE No.	CARGO No.	Gross (t)	Tare (t)	Net (t)
0004	20:44:36	00001	001	1.000	0.100	0.900
0005	20:45:00	00002	001	1.000	0.100	0.900
0006	20:45:10	00003	001	1.000	0.100	0.900
Total: GW : 7.003 t NW : 4.603 t						

(Standard) Duplicate format : (Vertical)

Weighing record sheet		Weighing record sheet		Weighing record sheet	
SERIAL No. : 0001		SERIAL No. : 0001		SERIAL No. : 0001	
Date : 2008-03-05		Date : 2008-03-05		Date : 2008-03-05	
Time : 20.45.10		Time : 20.45.10		Time : 20.45.10	
Car No. : 00002		Car No. : 00002		VEHICLE No. : 00002	
Number : 001		Number : 001		CARGO No. : 001	
Gross : 1.000(t)		Gross : 1.000(t)		Gross : 1.000(t)	
Tare : 0.100(t)		Tare : 0.100(t)		Tare : 0.100(t)	
Net : 0.900(t)		Net : 0.900(t)		Net : 0.900(t)	

(Standard) Duplicate format : (Horizontal)

Weighing record sheet				Date : 2008-03-05		
SERIAL No.	Time	VEHICLE No.	CARGO No.	Gross (t)	Tare (t)	Net (t)
0002	20.46.10	00002	001	1.000	0.100	0.900

Infill format : (eg)

WEIGHT BILL	
Operator keep first unite	
SERIAL No.	123
DATE	2004-03-05
TIME	12 .35 .28
VEHICLE No.	00001
CARGO No.	001
GROSS	1580 kg
TARE	80 kg
DISCOUNT	%
NET	1350 kg
CUSTOMER	
REMARK	



Add : Changxing Road 199 Jiangbei Investment Industriect park C District Ningbo, China.

Service hotline : 400-887-4165

800-857-4165

Fax : 0574-87562271

Postcode : 315033

Website : <http://www.kelichina.com>